

QUICK INSTALLATION GUIDE

THE IMAGE IS FOR REFERENCE ONLY.



DRACO|M1
MECHANICAL GAMING KEYBOARD

《English》

Thank you for purchasing the KWG™ DRACO M1 mechanical gaming keyboard. The new DRACO M1 keyboard with full color backlighting, your DRACO M1 offers brighter and clearer total lighting effects.

System Requirements

- Windows® XP/ Vista / 7 / 8 / 10
- PC with USB ports

Package Contents

- KWG™ DRACO M1 Gaming Keyboard
- Switch Puller

Hardware Installation


1. Insert the USB plug of the KWG™ DRACO M1 keyboard into an available USB port on the computer.
2. The “New Hardware Found” notification will be displayed. Follow the instructions on the screen to complete the hardware installation.

Introduction to DRACO M1 Keyboard Configuration

A. Twelve multimedia shortcut keys:

Fn + [F1~F6]	Multimedia Function	Fn + [F7~F12]	Multimedia Function
Fn + F1	My Computer	Fn + F7	Play/Pause
Fn + F2	www Web	Fn + F8	CD Stop
Fn + F3	Calculator	Fn + F9	Mute
Fn + F4	Media	Fn + F10	Volume-
Fn + F5	Pre Track	Fn + F11	Volume+
Fn + F6	Next Track	Fn + F12	Key Lock

B. Shortcut keys for switching lighting effects.




C. Speed adjustment of shortcut key:

There are 7 speed steps in existence (0~7 where 0 represents stop).




D. Keyboard backlight brightness level adjustment:

[Fn + ↑] increases brightness, [Fn + ↓] decreases brightness. There are 7 phases for brightness level adjustment; OFF / 20% / 30% / 40% / 60% / 80% / 100%




E. Swap between WASD and arrow key modes:

Press [Fn + W] once to enable swap mode. Press again to disable




F. Game mode:

Press [Fn + Win] once to lock the Windows key so there will be no response when it is pressed. Press again to unlock the key



DRACO M1 Keyboard Layout



Registering Your KWG™ DRACO M1

Please visit www.kworldgaming.com for online product registration.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for recycling of electrical and electronics equipment, or returned to the supplier for disposal.

《Magyar》

Köszönjük, hogy a KWG DRACO M1 típusú mechanikus billentyűzetét választotta. Az új DRACO M1 mechanikus billentyűzet háttérvilágítása tisztább és fényesebb effektusokat kínál.

Rendszer követelmények:

- Windows[®] XP/ Vista / 7 / 8 / 10
- PC USB csatlakozóval

A csomag tartalma

- KWG™ DRACO M1 Gaming billentyűzet
- Switch Puller

A termék csatlakoztatása


1. Csatlakoztassa a billentyűzet USB csatlakozóját a számítógép egy szabad USB csatlakozójához.
2. Ekkor megjelenik az “Új eszközt találtam” felirat a kijelzőn. Kövesse a képernyőn megjelenő utasításokat, hogy befejezze a telepítést.

A DRACO M1 billentyűzet konfigurálása

A. 12 multimédia gyorsbillentyű:

Fn + [F1~F6]	Multimédia funkció	Fn + [F7~F12]	Multimédia funkció
Fn + F1	Ez a gép/saját gép	Fn + F7	Play/Pause
Fn + F2	www Web	Fn + F8	CD Stop
Fn + F3	Számológép	Fn + F9	Némít
Fn + F4	Media	Fn + F10	Hangerő-
Fn + F5	előző szám	Fn + F11	Hangerő+
Fn + F6	következő szám	Fn + F12	Billentyűzár

B. Gyorsbillentyűk a fényhatások beállításához.




C. A gyorsbillentyű sebességének beállítása:

7 különböző fokozat állítható (0~7 ahol a 0=stop).




D. A billentyűzet háttérvilágítás fényerejének beállítása:

[Fn + ↑] fényerő növelése, [Fn + ↓] fényerő csökkentése. . A fényerő hét lépcsőben állítható; OFF / 20% / 30% / 40% / 60% / 80% / 100%




E. Váltás a WASD és iránybillentyűk között:

A váltás engedélyezéséhez nyomja meg egyszer az [Fn + W] gombot. Nyomja meg újra a kikapcsoláshoz.




F. Game mód:

Nyomja meg egyszer az [Fn + Win] gombot a Windows gomb lezárásához, így a gomb megnyomásakor nem fog válaszolni. Nyomja meg ismét a gombot a zárolás feloldásához.



DRACO M1 billentyűzet kiosztás



KWG™ DRACO M1 billentyűzet regisztrálása

Látogasson el a www.kworldgaming.com a termék online történő regisztrálásához.

Környezetvédelmi irányelv és a termék ártalmatlanítása

Ez a termék nem kezelhető háztartási vagy általános hulladékként annak élettartama végén. Át kell adni az elektromos és elektronikai berendezések újrahasznosításának megfelelő gyűjtőhelyre, vagy vissza kell küldeni a szállítóhoz.

